

EXD Deck Bolt Pattern

Note:

0" extension = 6.5 inches to rub rail
4" extension = 10.5 inches to rub rail

6" extension = 12.5 inches to rub rail
8" extension = 14.5 inches to rub rail

Print 1:1
8.5x11 Paper

NO SCALING
Zero Margins

See Note

Measure from here
to outer edge
of rub rail

**FIT CHECK ONLY
SEE INSTRUCTIONS**

Must Use All Counter Sunk Holes!

**DO NOT USE THIS
TEMPLATE TO DRILL
HOLES IN YOUR DECK**

Mount extends further inboard than shown

7EXD = 13"

9EXD = 15"

12EXD = 18.5"

15EXD = 21"

Rub Rail This Direction